

HOW DO YOU COMPLY WITH <USP 232/233>? HOW DO YOU KNOW WHEN TO CONDUCT E/L STUDIES? HOW DO YOU FULLY CHARACTERIZE AN ANTIBODY DRUG CO
HOW DO YOU MONITOR CHARGE VARIANTS AND DEGRADATIONS? HOW DO YOU DETECT POST-TRANSLATIONAL MODIFICATIONS? HOW DO YOU RE-OPTIMIZE AN ELISA
METHOD WHEN A REAGENT LOT CHANGES? HOW DO YOU IDENTIFY UNKNOWN METABOLITES? HOW DO YOU OPTIMIZE AN ANALYTICAL METHOD UNDER GMP? HO
KNOW IF A BIOSIMILAR IS SIMILAR ENOUGH? HOW DO YOU KNOW RAW MATERIALS ARE PURE? HOW DO YOU EVALUATE PRODUCT PACKAGING? HOW DO YOU IDENT
SOURCE OF CONTAMINATION? HOW DO YOU KNOW WHAT ANALYTICAL TECHNIQUE TO USE? HOW DO YOU SIMULTANEOUSLY TEST FOR TWO BYPRODUCTS? HOW DO
CHARACTERIZE AN UNKNOWN? HOW DO YOU EVALUATE STABILITY IN HOT, HUMID ENVIRONMENTS? HOW DO YOU KNOW RAW MATERIALS ARE PURE? HOW DO YOU
BIOSIMILAR IS SIMILAR ENOUGH? HOW DO YOU IDENTIFY UNKNOWN METABOLITES? HOW DO YOU OPTIMIZE AN ANALYTICAL METHOD UNDER GMP? HOW DO YOU
RE-OPTIMIZE AN ELISA METHOD WHEN A REAGENT LOT CHANGES? HOW DO YOU DETECT POST-TRANSLATIONAL MODIFICATIONS? HOW DO YOU MONITOR CHARGE
AND DEGRADATIONS? HOW DO YOU FULLY CHARACTERIZE AN ANTIBODY DRUG CONJUGATE? HOW DO YOU KNOW WHEN TO CONDUCT E/L STUDIES? HOW DO YOU
WITH <USP 232/233>? HOW DO YOU EVALUATE STABILITY IN HOT, HUMID ENVIRONMENTS? HOW DO YOU IDENTIFY THE SOURCE OF CONTAMINATION? HOW DO YOU KNOW WHAT ANA
CHARACTERIZE AN UNKNOWN? HOW DO YOU SIMULTANEOUSLY TEST FOR TWO BYPRODUCTS? HOW DO YOU KNOW WHAT ANALYTICAL TECHNIQUE TO USE? HOW
IDENTIFY THE SOURCE OF CONTAMINATION? HOW DO YOU EVALUATE PRODUCT PACKAGING? HOW DO YOU COMPLY WITH <USP 232/233>? HOW DO YOU KNOW W
CONDUCT E/L STUDIES? HOW DO YOU FULLY CHARACTERIZE AN ANTIBODY DRUG CONJUGATE? HOW DO YOU MONITOR CHARGE VARIANTS AND DEGRADATIONS?
YOU DETECT POST-TRANSLATIONAL MODIFICATIONS? HOW DO YOU RE-OPTIMIZE AN ELISA METHOD WHEN A REAGENT LOT CHANGES? HOW DO YOU IDENTIFY UN
METABOLITES? HOW DO YOU OPTIMIZE AN ANALYTICAL METHOD UNDER GMP? HOW DO YOU KNOW IF A BIOSIMILAR IS SIMILAR ENOUGH? HOW DO YOU KNOW RA
MATERIALS ARE PURE? HOW DO YOU EVALUATE PRODUCT PACKAGING? HOW DO YOU IDENTIFY THE SOURCE OF CONTAMINATION? HOW DO YOU KNOW WHAT ANA
TECHNIQUE TO USE? HOW DO YOU SIMULTANEOUSLY TEST FOR TWO BYPRODUCTS? HOW DO YOU CHARACTERIZE AN UNKNOWN? HOW DO YOU EVALUATE STABIL
HUMID ENVIRONMENTS? HOW DO YOU COMPLY WITH <USP 232/233>? HOW DO YOU KNOW RAW MATERIALS ARE PURE? HOW DO YOU KNOW IF A BIOSIMILAR IS S
HOW DO YOU ADJUST A FORMULATION FOR TIMED RELEASE? HOW DO YOU MAKE A DRUG IS ABUSE-DETERRENT? HOW DO YOU MAKE A METHOD MORE ROBUST?

HOW DO YOU MAKE BETTER DEVELOPMENT DECISIONS FASTER?

ICH STABILITY REQUIREMENTS Overcoming the Challenges

Wayland Rushing, Ph.D.
Director, Scientific Affairs




Stability Is Defined By...


- “resistance or the degree of resistance to chemical change or disintegration” – dictionary.com
- “the capacity of a drug product to remain within specifications established to ensure its identity, strength, quality and purity” – FDA, 1987, 1998
- “evidence on how the **quality** of a drug substance or drug product varies with time under the influence of a variety of environmental factors such as **temperature, humidity, and light**, and to establish a re-test period for the drug substance or a shelf life for the drug product and recommended storage conditions.” – ICH Q1A

- DP/DS Characteristics
 - Particle Size
 - Surface Area
 - Formulation
 - Excipients
 - pH
 - Preservatives
 - Solvents
 - Polymorphs
 - Crystalline Structure
- Environmental
 - Light
 - Heat
 - Oxygen
 - Humidity
- Container/Closure System
- Packaging


Stability Evolution




Stability Evolution



Stability Evolution



Stability Evolution



International Conference of Harmonisation of Technical Requirements for Registration of Pharmaceuticals for Human Use (ICH)

- **Japan:** Ministry of Health, Labour and Welfare, and Japan Pharmaceutical Manufacturers Association
- **Europe:** European Union and European Federation of Pharmaceutical Industries and Associations
- **USA:** Food and Drug Administration and Pharmaceutical Research and Manufacturers of America
- **Observers:** World Health Organization, European Free Trade Association, and Health Canada

To increase international harmonization of technical requirements

- Reduce unnecessary duplication
- Reduce animal testing
- Reduce development costs

ICH issues *Guidance*—NOT REGULATIONS

- **Q1A (R2)** – Stability testing of New Drug Substances and Products
- **Q1B** – Stability Testing: Photostability Testing of New Drug Substances and Products
- **Q1C** – Stability Testing for New Dosage Forms
- **Q1D** – Bracketing and Matrixing Designs for Stability Testing of New Drug Substances and Products
- **Q1E** – Evaluation of Stability Data
- **Q1F** – Stability Data package for Registration Applications in Climatic Zones III and IV - Withdrawn
- **Q5C** – Stability Testing of Biotechnological/Biological Products

- Provide evidence on how quality varies with
 - Time
 - Heat
 - Light
 - Humidity
- Establish re-test period for DS
- Establish Shelf Life

Climactic Zone

	Zone 1	Zone II	Zone III	Zone IV
Description:	Moderate	Mediterranean	Hot/Dry	Very Hot/Moist
Average Temp:	21 °C	25 °C	30 °C	30 °C
Average %RH:	45% RH	60% RH	35% RH	70% RH

- Guideline applies to zones I and II
 - EU, Japan and US
 - ✓ Data generated in any region is applicable to other two regions
 - Does not apply to ROW
 - ✓ WHO guidelines
- Defines recommended stability data for registration

- Long term
 - “normal” target storage conditions
- Intermediate
 - Stability condition which is designed to moderately increase the rate of degradation
- Accelerated
 - Stability condition which can be used as a potential worst case predictive condition for the long term conditions
- Stress testing
 - Intentional degradation by various chemical and non-physical stressing conditions
- Photostability
 - Determination of impact of light on the stability of the product

Stability Conditions

	Long Term	Intermediate	Accelerated
General Storage	25 °C/60% RH (12 months)	30 °C/65% RH (6 months)	40 °C/75% RH (6 months)
Refrigerated Storage	5 °C (12 months)	NA	25 °C/60% RH (6 months)
Frozen Storage	- 20 °C	NA	NA
Below -20 °C	Case-by-case		
Semi-Permeable	25 °C/40% RH Or 30 °C/35% RH (12 months)	30 °C/65% RH (6 months)	40 °C/ NMT 25% RH (6 months)

- 3 Primary Batches
 - Same process and synthetic route as final procedure
 - Quality should be same as production scale
 - container/closure should be the same or representative of proposed storage

- 3 primary batches
 - On each DP configuration
 - Unless bracketing/matrixing
 - Batches made by same process as filed
 - Each batch recommended to be made with different DS batches
 - Container/Closure should be same as proposed marketing packaging
 - Include secondary if needed

- Long Term
 - 1st year: every 3 months
 - 2nd year: every 6 months
 - Yearly after
- Accelerated
 - Three time points
 - 0, 3, and 6 months
- Intermediate
 - Every three months for 1 year
 - If needed as a result of Significant Change

- Drug Substance
 - Failure of specification
- Drug Product
 - 5% change in assay from initial value
 - Degradation specification failure
 - Failure for appearance, functional or physical attributes

What To Test?

- Attributes which are susceptible and may “influence quality, safety, and/or efficacy”
- Critical Quality Attributes
- Physical, Microbial, Chemical

Typical Quality Attributes

- Chemical
 - Loss of Efficacy
 - Assay/Potency
 - Increase in toxicity
 - Impurities
- Microbial impact
 - Sterility
- Change in Elegance
 - Taste
 - Smell
 - Color
- Physical
 - Dissolution
 - Hardness
 - Precipitation
 - Reconstitution
- Packaging Failures
- Loss of functionality
- Semi-Permeable
 - Water Loss

- Degradation Pathway determination
 - Acid, Base, Oxidation, Heat, Humidity, Light Stress
 - Determination of potential impurities
 - Determination of potential susceptibilities
- Analytical Methods
 - Help to direct method development/validation
 - Mass Balance
 - Stability Indicating Determination

- Perform GAP analysis on early phase methods
 - Ensure proper development for phase III expectations
- Employ stability indicating method(s)
- Methods should be validated
 - ICH Q2
 - FDA guidance (Feb 2014): Analytical Procedures and Methods Validation for Drugs and Biologics

- 1.2 million lux overall exposure
- Integrated UV of NLT 200 watt hours/m²

Option I

- “Sun” lamp: D65 (ISO 10977)
- Temperature exposure a concern

Option II

- Cool white fluorescent and near UV fluorescent lamps
- Longer stressing times

- Forced Degradation
 - Determination of photodegradation pathways
 - Analytical method support
- Confirmatory
 - Handling, packaging and labeling
- Presentation
 - Minimize physical changes
 - ✓ Evaporation, sublimation, etc.
 - Transparent container, i.e. Quartz
 - Solid, NMT 3mm thick

- Stepwise Procedure
 - Direct Exposure
 - ✓ If applicable
 - ✓ If acceptable change may stop
 - Immediate Pack
 - ✓ Primary container/closure
 - ✓ Orient to get uniform exposure
 - ✓ If acceptable change may stop
 - Marketing Pack
 - ✓ Secondary packaging/marketing packaging
 - ✓ If unacceptable change, reformulation/repackage

- Same API as existing product but in a different form
 - Different route of administration
 - ✓ Oral to parenteral
 - New Functionality
 - ✓ Immediate release to Sustained release
 - Different dosage form
 - ✓ Tablets to capsules
- Follow ICH Q1A and Q1B
 - Reduced testing may be justified

- Bracketing
 - Only extremes of ranges are tested
 - ✓ 1, 3, 5, 7 mg tablets
 - ✓ Only test 1 and 7 mg tested at all time points
 - ✓ Intermediate levels represented by extremes
- Matrixing
 - Subsets of samples are tested at time points
 - ✓ Assumes each subset is representative of all subsets

- Main Topics
 - How to analyze the data generated by ICH Q1A
 - When to use extrapolation
 - How to set retest/shelf life

Case 1 – No Change

- Accelerated Condition: No significant change
- Long Term Condition: No significant change
- Room Temperature
 - Statistical Evaluation may not be needed
 - Extrapolation of shelf life can be double but no more than 12 months beyond long term data
- Refrigerated
 - Extrapolation of shelf life can be 1.5 times but no more than 6 months beyond long term data


Case 2 – Some Change/Variability

- Accelerated Condition and/or Long Term Condition show change/variability
 - Data not amendable to interpretation
 - ✓ Supporting data may be used
 - ✓ Developmental batches
 - ✓ Extrapolation of shelf life can be 1.5 times but no more than 6 months beyond long term data
 - ✓ Refrigerated: shelf life can no more than 3 months beyond long term data
 - Data amenable to interpretation
 - ✓ Extrapolation of shelf life can be double but no more than 12 months beyond long term data
 - ✓ Refrigerated: shelf life can be 1.5 times but no more than 6 months beyond long term data


Case 3 – Significant Change

- Accelerated Condition: Significant change
- Intermediate Condition: No significant change
- Room Temperature
 - Long term data not amenable
 - ✓ Extrapolation of shelf life no more than 3 months beyond long term data
 - ✓ If backed up by supporting data
 - Long term data amenable
 - ✓ Extrapolation of shelf life can be 1.5 times but no more than 6 months beyond long term data
- Refrigerated
 - Extrapolation is not appropriate
 - Retest/Shelf life based on long term data

Why Accelerated Not Always Predictive



Why Accelerated Not Always Predictive




Case 4 – Significant Change

- Accelerated Condition: Significant change
- Intermediate Condition: Significant change
- Evaluation
 - Retest/Shelf life cannot exceed long term data

- Retest/Shelf life based on long term data
- Testing on single batch at 5 °C or 25 °C recommended for excursions
- For storage below -20 °C
 - Addressed on case-by-case basis
 - Retest/Shelf-life based on long term data

- Regression Analysis
 - May be linear or non-linear
 - Plot intersection of 95% confidence interval with proposed specification
 - ✓ One-sided or two-sided confidence intervals
 - SAS, Slimstat, JMP, etc
 - Analysis should take into account study design to ensure statistical significance

Example Plot



- In general ICH Q1A can be applied
 - Special Considerations should be made
 - ✓ Complexity of stability indicating methods
 - ✓ Availability of lots
 - ✓ Retest/Expiry based on long-term, real-time data

- Accelerated/Long Term stability both demonstrated a loss of mass balance (HPLC method)
 - Scenario 1: Impurities with different spectral properties
 - Scenario 2: Inappropriate methods
- Both Scenario 1 and 2
 - Stress studies inadequate
 - Degradation Pathway not understood
 - Method development didn't use appropriately stressed samples
 - New methods developed using alternate detection techniques

- Impurity peak grew over 6 months then decreased
 - Trending at 6 months would have had expiry at 12 months
 - Impurity decreased at 9 and 12 month time points
- Isolation and ID performed
 - Impurity was an intermediate
 - ✓ $A + B \rightarrow C$
 - ✓ $C \rightarrow D$
 - Reaction product (D) found in the solvent front
 - ✓ New method developed

Download this presentation
www.eag.com/stability