

APPLICATION NOTE

TXRF and SURFACESIMS.XP

The Total Solution For Surface Contamination Measurements

DISCUSSION

Ultra-clean surfaces are critically important to successful processing of semiconductor devices. Device failure can often be attributed to surface contaminants such as transition metals and alkali atoms. In order to control contaminants, it is necessary to identify and quantify them. Utilizing both TXRF and SURFACESIMS.XP provides the total solution with the best value for surface contamination measurements on semiconductor surfaces.

FEATURES OF TXRF

- Survey technique; detection of elements from S to U.
- Non-destructive, automated analysis in a clean room environment.
- Whole wafers 100 - 300 mm. Smaller wafers down to 50 mm may be mounted for analysis.
- Large analysis area (10 mm diameter) at a glancing angle below the critical angle.
- Detection limits ranging between 109-1010 atoms/cm² for most metals.
- Long term precision: <20% RSD.
- ASTM Method (F1526-95)
- Applicable substrates: Si, SiO₂, SiC, GaAs, Sapphire, others

As a survey technique, TXRF provides high sensitivity multi-element surface contamination measurements at low cost.




Figure 1: TXRF spectrum of metallic impurities on Si wafer

FEATURES OF SURFACESIMS.XP

- Element-specific detection of all elements and isotopes, especially light elements (H-S) where TXRF has poor detection efficiency.
- ASTM methods (F1617-98) for Al, Na, K and Fe contamination on silicon and epi substrates.
- Measurement of near surface depth distributions, providing both surface and in depth detection of contamination.
- Small analysis areas (minimum 50x50 μm²) - very useful for device applications and for navigating measurements between airborne particles.
- Detection limits ranging between 10⁸-10⁹ atoms/cm² for most metals.
- Long term precision: ~10% RSD.
- Applicable substrates: Si, SiO₂, SiC

SURFACESIMS.XP provides (1) areal densities of surface contaminants and (2) information about the near surface depth distribution of contaminants. This represents an important advantage over TXRF, VPD-AAS, and VPD-ICPMS.




Figure 2: SURFACESIMS.XP depth profiles of Aluminum in Si

TXRF and SURFACESIMS.XP The Total Solution For Surface Contamination Measurements

Typical Detection Limits of Selected Elements (10^{10} atoms/cm²) on Silicon

Elements	TXRF	SURFACESIMS.XP	Elements	TXRF	SURFACESIMS.XP
Li	*	0.001	V	2	0.01
B	*	0.1	Cr	0.7	0.03
C	*	100	Mn	0.6	0.05
N	*	300	Fe	0.3	0.05
F	*	40	Ni	0.3	0.5
Na	*	0.01	Cu	0.3	0.3
Mg	*	0.05	Zn	0.8	0.5
Al	*	0.05	As	3	0.5
P	*	1	Mo	*	0.1
S	50	2	Rh	20	0.7
Cl	20	20	Sb	20	0.1
K	40	0.01	Sn	*	0.1
Ca	10	0.05	Ta	3	0.1
Ti	2	0.05	W	10	0.2

* These elements cannot be detected by TXRF or cannot be measured at practical levels. In some cases, spectral interferences prevent detection at low levels.